

arzum OKKA

RICH SPIN PRO



KULLANMA KILAVUZU
INSTRUCTION MANUAL
GEBRAUCHSANWEISUNG
MANUEL D'INSTRUCTIONS

ИНСТРУКЦИЯ ПО
ЭКСПЛУАТАЦИИ

دليل المستخدم

DEAR VALUED CUSTOMER;

We would like to thank you for choosing Arzum OKKA Rich Spin M. We recommend you to read this Manual carefully before using Arzum OKKA Rich Spin M, and keep the Manual as it may be necessary in the future. Arzum OKKA Rich Spin M should only be used by people with knowledge of the safe use instructions given in this guide.

Terms of warranty and warranty certificate of your machine are also included in this manual.

*Our company does not take responsibility for any damage caused by improper handling contrary to the instructions in this manual or any application other than usage area and repairing to the product by other persons or parties than Arzum authorized services, and such conditions will make this warranty void.

Opening Package and First Use:

Before first use, take the machine and accessories out of the box, check for damage and malfunctions. If there are any damage or malfunctions, do not use the machine and apply to Arzum Authorized Service.

This product complies with all binding CE labeling directives.



It complies with AEEE Regulation. This machine should not be disposed of as it is combined with recyclable parts in accordance with AEEE instructions. Please apply to the nearest civic amenity site or Arzum authorized service in order to recycle this machine.



OKKA RICH SPIN PRO

OK0026 / OK0026-K

TABLE OF CONTENTS

1. IMPORTANT SAFEGUARDS	24
2. GENERAL AND TECHNICAL SPECIFICATIONS OF THE MACHINE	28
3. USE OF MACHINE	29
4. BREWING (For Classic Turkish Coffee Mode)	31
5. BREWING (For Slow Brew Mode)	33
6. BREWING (For Turkish Coffee with Milk Mode)	34
7. BREWING (For Hot Choco Mode)	35
8. BREWING (For Beverages With Milk Mode)	36
9. MILK WARMING	37
10. MILK FROTHING (Hot or Cold)	38
11. CLEANING AND MAINTENANCE	40
12. HANDLING AND SHIPMENT	41

1. IMPORTANT SAFEGUARDS

Make sure that the voltage printed on the technical specifications label of the Arzum OKKA Rich Spin Pro corresponds to the mains voltage of your location. Our company cannot be held responsible for malfunctions caused by any voltage differences and therefore, any potential malfunction will be out of warranty.

The Arzum OKKA Rich Spin Pro must only be plugged into a grounded socket outlet connected in accordance with the regulations. To prevent damage to your appliance, please do not use extension cables that do not provide enough current.

To avoid hazards, repairs to this electrical appliance or its power cord must be carried out by authorized customer service personnel.

If repairs are necessary, please contact Arzum Customer Service. Our company cannot be held responsible for malfunctions that may occur due to misuse and any malfunction that may occur for this reason will be treated outside the scope of the warranty.

To protect against electric shock, DO NOT clean and immerse machine and

power cord in water.

Since the appliance is electrically powered, there is a risk of electric shock, so never touch the plug with wet hands.

This appliance must be used by persons who have been given information, supervision or instruction concerning its safe use and who understand the hazards involved. Children must not play with the appliance and the mains cable, nor must children be allowed to cook or clean the appliance without adult supervision. Keep the appliance and power cord out of the reach of children under 8 years of age.

Caution: Keep all packaging materials away from children, as they are a potential source of danger that can lead to death by suffocation.

This appliance is intended for use in the home and similar locations, such as the following locations:

- Staff kitchen areas in shops, offices and other work environments,
- Farmhouses,
- Places used by customers in motels, hotels and other residential-type environments,
- Sleeping places and places where breakfast is served.

Do not use the appliance outdoors, always protect it from zero or sub-zero temperatures.

ALWAYS use Arzum OKKA Rich Spin Pro on flat and uneven surfaces. Do not place on the edge of a table or countertop, a small impact may cause your appliance to fall to the floor. Please note that your appliance may be filled with hot coffee.

Do not use Arzum OKKA Rich Spin Pro on hot surfaces, near heat sources, open flames or flammable vapors. (Ex. hot stove top, radiator, stove, etc.) Make sure that the power cable does not hang from the table or worktop and does not come into contact with other appliances.

Do not leave Arzum OKKA Rich Spin Pro unattended and unattended while it is in operation.

When using your appliance for the first time, simply put water into coffee pot and operate your appliance then discard the waste water.

Do not start the coffee brewing process until you have poured water/milk into the coffee pot. There is water-secure security implementation in your appliance. In case operating without water, the appliance will shut off after a while and will not be rerun until it cools down.

Do not use the coffee pot in any heater other than this machine. (Ex: on oven, microwave oven etc.)

Serve your brewed coffee with cup, do not drink from the coffee pot.

To handle/carry the coffee pot always use a carrying handle

Please, unplug your appliance from the outlet before cleaning. For detailed information on cleaning the appliance, please refer to the Cleaning and Maintenance section.

Always unplug the Arzum OKKA Rich Spin Pro when it is not in use for a long period of time and/or in case of any malfunction and/or in case of a dangerous situation.

NEVER pull on the mains cable when unplugging the plug from the socket outlet; always pull by holding the plug itself.

When cleaning and servicing the appliance, make sure that the plug is not in the socket.

Only use the appliance in conjunction with the supplied power transmission base.

3. USE OF MACHINE

altitude detection setting specified in the manual before the first use.

Use your machine with coffee pot with mixer for your coffee to reach the ideal flavor. Make sure that the mixer is fully seated to avoid splashing.

Wipe the main body of your appliance clean before first use. Wipe the outside of the coffee pot with a damp cloth. For the first use, start the appliance by filling the coffee pot with water up to the MAX level and pour this water out and let the appliance cool down.

Your Arzum OKKA Rich Spin Pro Turkish Coffee Machine heats up during use, so do not touch the hot surfaces of the appliance.

You can brew coffee for 1-5 people with your Arzum OKKA Rich Spin Pro Turkish Coffee Machine. The maximum capacity for the milk mode is 4 cups.

When your machine is plugged in, all lights turn on and off at the same time. Then, when you long press the on/off button on the panel, all the LEDs on the panel will blink once with a beep sound, and then the initial mode, Turkish Coffee mode, will appear brighter than the other modes.

Put enough water or milk in the coffee pot according to the number of people. Use the Arzum OKKA Rich Spin Pro measuring spoon to add the desired amount of Turkish coffee. Add the desired amount of sugar. Make sure that the mixture in the coffee pot does not exceed the Max marks inside the coffee pot. To prepare 1 cup of Turkish coffee in milk coffee mode, use half a cup of water, half a cup of milk and half a cup of Turkish coffee.

When you place the coffee pot on the power transmission base and turn the rotary knob to the desired mode position, the icon light for the selected mode will illuminate blue and the other mode lights will turn off. When the brewing process starts, the stirrer in the coffee pot will automatically stir your coffee. After the brewing process is finished, your device will give an audible warning for 5 seconds and the selected mode light will flash.


Never remove the coffee pot while brewing is in progress. When you remove the coffee pot for any reason during the brewing process, the product will give an audible warning and all function icons on the panel will turn off.

When the brewing process is finished, you can easily serve it by removing the pot. Make sure to clean the coffee pot after each use. Do not wash the outer surface of the coffee pot under the tap, wipe it with a damp cloth. NEVER wash the coffee pot in the dishwasher.

AUTO BREWING ALTITUDE DETECTION SYSTEM SETTING

Arzum OKKA Rich Spin Pro has a smart auto brewing altitude detection system that detects the ideal brewing temperature at its location and enables you to make Turkish coffee with the same flavor anywhere in the world.


The boiling point of water depends on the difference in altitude relative to sea level. Therefore, when the altitude at which your appliance is used changes, you can manually adjust the brewing point of your appliance.

- a. Plug the appliance into the socket.
- b. Press the On/Off button (rotary knob) on the panel.
- c. All LEDs on the panel will flash and a double beep will sound.
- d. Select the slow brew mode () by turning the rotary knob. Do not press.
- e. Remove the coffee pot and press the rotary knob briefly.
- f. After the beep, the LED for the Slow brew mode will start blinking, then the manual calibration mode will be active.
- g. Pour water into the coffee pot up to the MAX level and insert the coffee pot into its slot.
- h. Wait until the water in the coffee pot boils.
- i. When the calibration process is finished, your device will beep for 5 seconds and the Slow brew LED light will flash.
- j. When you remove the coffee pot from its slot, your product will beep once and all the LEDs will turn off.

BREWING TEMPERATURE SETTING

You can increase or decrease the temperature of coffee brewing as you wish, bringing it to the desired temperature.

Increasing the temperature:

- Plug the product into the socket.
 - Press and hold the On/Off button (rotary knob).
 - All LEDs on the panel will flash once and a double beep will sound.
- Remove the coffee pot from its slot.
- Select the Milk Coffee mode () by turning the rotary knob. Do not press.

- Remove the coffee pot from the slot.
- Press the rotary knob 1 time.
- After the beep, the LED for the Turkish Coffee with Milk mode will start flashing and the manual brewing temperature setting mode will be active.
- You can increase the temperature by turning the rotary knob clockwise. A beep will sound each time the rotary knob is turned.
- The temperature will increase by 1°C for each rotation. The maximum permissible temperature increase is 1°C.
- A double beep will sound when the limit is reached.

Temperature Reduction:

- Plug the product into the socket.
- Press and hold the On/Off button (rotary knob).
- All LEDs on the panel will flash once and a double beep will sound.
- Select the Milk Coffee mode (☞) by turning the rotary knob. Do not press.

· Remove the coffee pot from the slot.

· Press the rotary knob 1 time.

· After the beep, the LED for the Milk Coffee mode will start flashing and the manual brewing temperature setting mode will be active.

· You can decrease the temperature by turning the rotary knob counterclockwise. A beep will sound each time the rotary knob is turned.

· The temperature will decrease by 1°C for each rotation. The maximum permissible temperature decrease is 3°C.

· A double beep will sound when the limit is reached.



4. BREWING (For Classic Turkish Coffee Mode)

1. Plug in your appliance.
2. Press and hold the On/Off button (rotary knob) on the panel.

Note: Pay attention not to exceed water-coffee-sugar or milk mixture beyond the MAX COFFEE level line in the coffee pot as the size of cups you are using may differ.

3. To prepare 1 cup of Turkish coffee; Put 1 Arzum OKKA measuring spoon of Turkish coffee, 1 cup of water and any amount of sugar you want into the coffee pot.

4. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all leds on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light

5. Turn the rotary knob to select the Classic Turkish Coffee mode  and press.

6. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

7 After brewing process has finished, your appliance will give warning beep for 5 seconds and the led light and ambient lighting for the selected brewing mode will flash.

8. After brewing process has finished, you can serve your coffee by pouring into the cup.



9. If you displace the coffee pot before the brewing process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the brewing process.

If the coffee pot is put back after being removed, the brewing process will not continue.

and finish the brewing process.

If the coffee pot is put back after being removed, the brewing process will not continue.

5. BREWING (For Slow Brew Mode)

1. Plug in your appliance.
2. Press and hold the On/Off button (rotary knob) on the panel.

Note: Pay attention not to exceed water-coffee-sugar or milk mixture beyond the MAX COFFEE level line in the coffee pot as the size of cups you are using may differ.

3. To prepare 1 cup of Turkish coffee; Put 1 Arzum OKKA measuring spoon of Turkish coffee,

1 cup of water and any amount of sugar you want into the coffee pot.

4. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all leds on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light

5. Turn the rotary knob to select the Slow Brew mode () and press.

6. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

7. After brewing process has finished, your appliance will give warning beep for 5 seconds and the led light and ambient lighting for the selected brewing mode will flash.

8. After brewing process has finished, you can serve your coffee by pouring into the cup.

9. If you displace the coffee pot before the brewing process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the brewing process.

If the coffee pot is put back after being removed, the brewing process will not continue.

6. BREWING (For Turkish Coffee with Milk Mode)

1. Plug in your appliance.
2. Press and hold the On/Off button (rotary knob) on the panel.

Note: In Turkish Coffee with Milk mode, your device can prepare coffee for up to 4 people at the same time. Pay attention not to exceed water-milk-coffee-sugar mixture beyond the MAX MILK level line in the coffee pot as the size of cups you are using may differ.

3. To prepare 1 cup of Turkish coffee with milk; put 1/2 Arzum OKKA measuring spoon of Turkish coffee, half a cup of water, half a cup of milk and the desired amount of sugar into the coffee pot.
4. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all leds on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light

5. Turn the rotary knob to select the Turkish Coffee with Milk mode () and press.

6. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

7. After brewing process has finished, your appliance will give warning beep for 5 seconds and the LED light and ambient lighting for the selected brewing mode will flash.

8. After brewing process has finished, you can serve your coffee by pouring into the cup.

9. If you displace the coffee pot before the brewing process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the brewing process.

If the coffee pot is put back after being removed, the brewing process will not continue.

7. BREWING (For Hot Choco Mode)

In Hot Choco mode, it is recommended to use 20 g dark/milk tablet chocolate and 200 ml milk.

1. Plug in your appliance.
2. Press and hold the On/Off button (rotary knob) on the panel.

Note: Pay attention not to exceed water-milk-sugar mixture or milk mixture beyond the 200 ML level line in the coffee pot as the size of cups you are using may differ.

3. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all LEDs on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light



4. Turn the rotary knob to select the Hot Choco mode (☞) and press.
and press.

6. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

7. After brewing process has finished, your appliance will give warning beep for 5 seconds and the LED light and ambient lighting for the selected brewing mode will flash.

8. After brewing process has finished, you can serve your beverage by pouring into the cup.

9. If you displace the coffee pot before the brewing process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the brewing process.

If the coffee pot is put back after being removed, the brewing process will not continue.

8. BREWING (For Beverages With Milk Mode)

You can prepare the following beverages with your device in Beverages with Milk mode;

- Turpentine (Menengiç) Coffee
- Milk with honey
- Salep
- Matcha Latte
- Other recipes that can be prepared with coffee syrups

To prepare a drink in the Beverages with Milk mode;


1. Plug in your appliance.
2. Press and hold the On/Off button (rotary knob) on the panel.

Note: Pay attention not to exceed water-milk-coffee-sugar mixture or milk mixture beyond the 200 ML level line in the coffee pot as the size of cups you are using may differ.

3. In Milk Coffee Mode, your appliance can prepare up to 4 drinks at a time.

4. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all LEDs on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light

5. Turn the rotary knob to select the Beverages with Milk mode () and press.

6. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

7. After brewing process has finished, your appliance will give warning beep for 5 seconds and the LED light and ambient lighting for the selected brewing mode will flash.

8. After brewing process has finished, you can serve your beverage by pouring into the cup.

9. If you displace the coffee pot before the brewing process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the brewing process.

If the coffee pot is put back after being removed, the brewing process will not continue.

9. MILK WARMING

To warm the milk;


1. Plug in your appliance.

2. Press and hold the On/Off button (rotary knob) on the panel.

Note: Pay attention not to exceed amount of milk beyond the MILK level line in the coffee pot as the size of cups you are using may differ.

3. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all LEDs on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light

4. Turn the rotary knob to select the Milk Warming mode () and press.

5. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

6. After warming process has finished, your appliance will give warning beep for 5 seconds and the LED light and ambient lighting for the selected brewing mode will flash.

7. After the warming process is over, pour the milk into a glass and serve.
8. If you displace the coffee pot before the warming process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the warming process.

If the coffee pot is put back after being removed, the warming process will not continue.

10. MILK FROTHING (Hot or Cold)

1. Plug in your appliance.
2. Press and hold the On/Off button (rotary knob) on the panel.

Note: Pay attention not to exceed amount of milk beyond the 120 ML level line in the coffee pot as the size of cups you are using may differ.

3. Insert the coffee pot into the machine.

Note: If the Coffee pot is not in the place or not place in its slot, all LEDs on the control panel will remain off but coffee pot is not in the place warning light and ambient lighting will continue to light

4. For cold milk frothing;

Turn the rotary knob to select the Cold Milk Frothing mode () and press.

For hot milk frothing;

Turn the rotary knob to select the Hot Milk Frothing mode () and press.

5. When any brewing mode is selected, a beep will sound and only the blue led for the selected brewing mode will remain on and the brewing process will start.

6. After warming process has finished, your appliance will give warning beep for 5 seconds and the LED light and ambient lighting for the selected brewing mode will flash.

7. After the frothing process is over, pour the milk into a glass and serve.

8. If you displace the coffee pot before the frothing process is over, the red colored warning light that coffee pot is not in its place and all function lights will flash and your appliance will give a warning sound and finish the warming process.

If the coffee pot is put back after being removed, the warming process will not continue.



AMOUNT	CLASSIC	SLOW BREW	MILK COFFEE
1 CUP	0.5-1.5 MIN	2.5-3.5 MIN	1-2 MIN
2 CUPS	1-2 MIN	3-4 MIN	2-3 MIN
3 CUPS	2-3 MIN	3.5-4.5 MIN	3-4 MIN
4 CUPS	2.5-3.5 MIN	4-5 MIN	4-5 MIN
5 CUPS	3-4 MIN	5-6 MIN	-

AMOUNT	BEVERAGES WITH MILK	HOT CHOCOLATE	MILK WARMING	HOT & COLD MILK FROTHING
120 ml	2-4 MIN	3-4 MIN	1-2 MIN	1-2 MIN

11. CLEANING AND MAINTENANCE

Please, unplug your appliance from outlet before cleaning. Pour some water into the coffee pot and shake it.

NEVER clean the coffee pot by immersing it in water or washing it in the dishwasher.

Wipe the main body of your appliance, including the energy transmission base outside the coffee pot, only with a dry or damp cloth, **NEVER** clean it by immersing it in water or washing it in the dishwasher.



Do not clean any accessories of your machine using harsh and chemical cleaners (bleach, salt spirit, etc.) other than the cleaners used for this type of equipment. Do not use abrasive cleaners, metal objects, scratching hard sponges, wire cleaners or hard brushes to clean the appliance.

Cleaning Suggestion After Preparing Turkish Coffee with Milk and Beverages with Milk

You can also brew milky beverages such as milk coffee, hot chocolate and salep in our product. After brewing such beverages, rinse the coffee pot with water. The coffee pot rinsed with water will cool down a bit.

Then remove the stirring apparatus inside and wipe the inside of the coffee pot with the cleaning brush provided with your device or with a soft material such as a dishwashing sponge or cloth to easily clean the residue* without using chemicals such as detergents.

You may wash the removed mixing apparatus under the tap. Put the cleaned apparatus back to its place and make the product ready for use. Make sure that the apparatus is fully seated. If it is not fully seated, it may cause splashing.

*The cleaning of the residue/crust part will vary according to the material used, the amount of material, and the waiting time after brewing.

Removing Calcification

Lime inside the water used in time may pile up inside the coffee pot and thus may reduce the performance of your appliance.

You can clean the coffee pot of your appliance with decalcifying products specially designed for electric kitchen appliances or try eco-friendly solutions such as white vinegar.

To clean the coffee pot of your appliance with white vinegar; add enough white vinegar to the appliance to cover the bottom of the coffee pot and leave it for 1 hour, then drain the vinegar and rinse the coffee pot 2-3 times with clean water.

12. HANDLING AND SHIPMENT

Your device should be kept in its original box to prevent damage to its components during handling and shipping.

Keep the product in its normal position during handling.

Do not drop your device during shipping and protect against impacts.

Failures and damages during shipping after the delivery of the product to the customer are not covered by the warranty.

عملينا المحترم

نود أن نشرك على اختيار أرزوم أوكا ريتش سبين برو (Rich Spin Pro Arzum OKKA).
نوصيك بشدة بقراءة هذا الدليل بعناية قبل استخدام أرزوم أوكا ريتش سبين برو (Arzum OKKA Rich Spin Pro) والاحتفاظ بهذا الدليل في حال احتجت إليه لاحقا.
يجب استخدام أرزوم أوكا ريتش سبين برو (OKKA Rich Spin Pro Arzum) فقط من قبل الأشخاص المطلعين على تعليمات الاستخدام الآمن الواردة في هذا الدليل.
يتم أيضا تضمين شروط الضمان وشهادة الضمان لجهازك في هذا الدليل.

* لا تتحمل شركتنا المسؤولية عن أي أضرار قد تحدث إذا تم استخدام جهازك بطريقة لا تتوافق مع التعليمات الواردة في دليل المستخدم هذا ، واستخدامه في مكان آخر غير منطقة الاستخدام الخاصة به وإصلاحه في مكان آخر غير خدمات أرزوم المعتمدة وسيكون جهازك خارج الضمان.

فتح الحزمة والاستخدام الأول:

قبل الاستخدام لأول مرة ، أخرج الجهاز والملحقات من الصندوق ، وتحقق من التلف والأعطال.
إذا كان هناك أي عطل أو تلف في الجهاز ، فلا تستخدم الجهاز واتصل بخدمة أرزوم المعتمدة.

يتوافق هذا المنتج مع جميع توجيهات وضع العلامات CE الملزمة.



يتوافق مع تنظيم AEEE

نظرا لأن هذا الجهاز يتكون من أجزاء قابلة لإعادة التدوير وفقا لتوجيهات AEEE، فلا يجب أن تلقى في سلة المهملات. يرجى الاتصال بأقرب مركز تجميع أو مركز خدمة معتمد من أرزوم لإعادة تدوير هذا الجهاز.



OKKA RICH SPIN PRO

OK0026 / OK0026-K

المحتويات

108	1. تحذيرات مهمة للسلامة
111	2. المواصفات العامة والفنية للآلة
112	3. استخدام الجهاز
114	4. تخمير (لوضع القهوة التركية الكلاسيكية تخمير)
115	5. تخمير (لوضع التحضير البطيء)
116	6. تخمير (للقهوة التركية مع وضع الحليب)
117	7. تخمير (لوضع الشوكولاته الساخنة)
118	8. تخمير (لوضع مشروب الحليب)
119	9. تسخين الحليب
119	10. رغوة الحليب (حارًا أو بارد)
121	11. التنظيف والعناية
122	12. الحمل والنقل

1. تحذيرات مهمة للسلامة

تأكد من أن الجهد المطبوع على ملصق "المواصفات الفنية" الخاص بـ أرزوم أوكا ريتش سين برو (Arzum OKKA Rich Spin Pro) يتوافق مع جهد التيار الكهربائي لموقعك. لا يمكن اعتبار شركتنا مسؤولة عن أي أعطال قد تحدث في حالة حدوث عدم التوافق، ويتم التعامل مع هذا العطل خارج نطاق الضمان.

تأكد من أن الجهد المطبوع على ملصق "المواصفات الفنية" الخاص بـ أرزوم أوكا ريتش سين برو (Arzum OKKA Rich Spin Pro) يتوافق مع جهد التيار الكهربائي لموقعك. لا تستخدم أسلاك التمديد التي توفر تيار غير كاف لتجنب إتلاف جهازك.

لتجنب المخاطر ، يجب إجراء إصلاحات لهذا الجهاز الكهربائي أو سلك الطاقة الخاص به بواسطة موظفي خدمة العملاء المعتمدين.

إذا كانت الإصلاحات ضرورية، يرجى الاتصال بخدمة عملاء أرزوم. لا يمكن تحميل شركتنا المسؤولية عن الأعطال التي قد تحدث بسبب سوء الاستخدام وسيتم التعامل مع أي عطل قد يحدث لهذا السبب خارج نطاق الضمان.

للحماية من الصدمات الكهربائية ، لا تقم بتنظيف وغمر الماكينة وسلك الطاقة في الماء.

نظرا لأن الجهاز يعمل بالطاقة الكهربائية ، فهناك خطر حدوث صدمة كهربائية ، لذلك لا تلمس القابس أبدا بأيدي مبللة.

يجب استخدام هذا الجهاز من قبل الأشخاص الذين تم إعطاؤهم معلومات أو إشرافا أو تعليمات بشأن استخدامه الآمن والذين يفهمون المخاطر التي تنطوي عليها. يجب ألا يلعب الأطفال بالجهاز وكابل التيار الكهربائي ، ولا يسمح للأطفال بطهي الجهاز أو تنظيفه دون إشراف الكبار. احتفظ بالجهاز وسلك الطاقة بعيدا عن متناول الأطفال دون سن 8 سنوات.

أنذر: احتفظ بجميع مواد التغليف بعيدا عن متناول الأطفال ، لأنها مصدر خطر محتمل يمكن أن يؤدي إلى الوفاة عن طريق الاختناق.

هذا الجهاز مخصص للاستخدام في المنزل والمواقع المماثلة ، مثل المواقع التالية:

- مناطق مطبخ الموظفين في المحلات التجارية والمكاتب وبيئات العمل الأخرى ،

- بيوت المزارع؛

- الأماكن التي يستخدمها العملاء في الموتيلات والفنادق وغيرها من البيئات السكنية ،

- أماكن النوم وأماكن تقديم وجبة الإفطار.

لا تستخدم الجهاز في الهواء الطلق ، قم دائما بحمايته من درجات الحرارة الصفرية أو دون الصفر.

استخدم دائما أرزوم أوكا ريتش سبين برو (Arzum OKKA Rich Spin Pro) على الأسطح المستوية وغير المستوية. لا تضعه على حافة طاولة أو سطح عمل ، فقد يتسبب تأثير صغير في سقوط جهازك على الأرض. يرجى ملاحظة أن جهازك قد يكون ممتلئا بالقهوة الساخنة.

لا تستخدم أرزوم أوكا ريتش سبين برو (Arzum OKKA Rich Spin Pro) على الأسطح الساخنة أو بالقرب من مصادر الحرارة أو اللهب المكشوف أو الأبخرة القابلة للاشتعال. (على سبيل المثال ، سطح الموقد الساخن ، المبرد ، الموقد ، إلخ.) تأكد من أن كبل الطاقة لا يتدلى من الطاولة أو سطح العمل ولا يتلامس مع الأجهزة الأخرى.

لا تترك أرزوم أوكا ريتش سبين برو (Arzum OKKA Rich Spin Pro) دون مراقبة ودون مراقبة أثناء تشغيله.

عند استخدام جهازك لأول مرة ، ما عليك سوى وضع الماء في وعاء القهوة وتشغيل جهازك ثم التخلص من مياه الصرف.

لا تبدأ عملية تخمير القهوة حتى تصب الماء / الحليب في وعاء القهوة. هناك تطبيق أمان آمن للمياه في جهازك. في حالة التشغيل بدون ماء ، سيتم إيقاف تشغيل الجهاز بعد فترة ولن يتم إعادة تشغيله حتى يبرد

لا تستخدم وعاء القهوة في أي سخان آخر غير هذا الجهاز. (على سبيل المثال: في الفرن ، فرن الميكروويف ، إلخ.)

قدمي قهوتك المخمرة مع فنجان ، ولا تشرب من وعاء القهوة. للتعامل مع / حمل وعاء القهوة ، استخدم دائما مقبض حمل

افصل قابس الجهاز من المأخذ الكهربائي قبل التنظيف. للحصول على معلومات مفصلة حول تنظيف الجهاز ، يرجى الرجوع إلى قسم "التنظيف والصيانة".

افصل دائماً أرزوم أوكا ريتش سين برو (Arzum OKKA Rich Spin Pro) من المقبس عندما لا يتم استخدامه لفترة طويلة من الزمن و / أو في حالة حدوث عطل و / أو في حالة حدوث موقف خطير. لا تقم أبداً بسحب كابل التيار الكهربائي عند فصل القابس من مأخذ المقبس ؛ اسحب دائماً عن طريق الضغط على القابس نفسه. عند تنظيف الجهاز وصيانته ، تأكد من أن القابس ليس في المقبس. استخدم الجهاز فقط مع قاعدة نقل الطاقة المرفقة.

3. استخدام الجهاز

نوصي بضبط إعداد كشف نقطة الإنتقاع المحددة في الدليل يدويًا قبل الاستخدام لأول مرة من أجل الحصول على أفضل مذاق. استخدم ماكينتك مع الخلاط الموجود في إناء الطهي لكي تصل قهوتك إلى المذاق المثالي. تأكد من ثبات الخلاط في مكانه بشكل تام من أجل تجنب التناثر. امسح الجسم الرئيسي لجهازك نظيفًا قبل الاستخدام لأول مرة. امسح الجزء الخارجي من وعاء القهوة بقطعة قماش مبللة. للاستخدام الأول ، ابدأ تشغيل الجهاز عن طريق ملء وعاء القهوة بالماء حتى مستوى MAX وسكب هذا الماء واترك الجهاز يبرد.

تسخن ماكينة القهوة التركية أرزوم أوكا ريتش سبين برو (Rich Spin Pro Arzum OKKA) أثناء الاستخدام ، لذلك لا تلمس الأسطح الساخنة للجهاز. يمكنك تحضير القهوة ل 1-5 أشخاص باستخدام ماكينة القهوة التركية أرزوم أوكا ريتش سبين برو (Arzum OKKA Rich Spin Pro). السعة القصوى لوضع الحليب هي 4 أكواب.

عند توصيل جهازك، يتم تشغيل جميع الأضواء وإيقافها في نفس الوقت. بعد ذلك ، عندما تضغط لفترة طويلة على زر التشغيل / الإيقاف على اللوحة ، ستومض جميع مصابيح LED الموجودة على اللوحة مرة واحدة بصوت صفير ، ثم سيظهر الوضع الأولي ، وضع القهوة التركية ، أكثر إشراقًا من الأوضاع الأخرى.

ضع كمية كافية من الماء أو الحليب في وعاء القهوة حسب عدد الأشخاص. استخدم ملعقة قياس أرزوم أوكا ريتش سبين برو (OKKA Rich Spin Pro Arzum) لإضافة الكمية المطلوبة من القهوة التركية. أضف الكمية المطلوبة من السكر. تأكد من أن الخليط الموجود في وعاء القهوة لا يتجاوز علامات ماكس داخل وعاء القهوة. لتحضير 1 كوب من القهوة التركية في وضع قهوة الحليب ، استخدم نصف كوب من الماء ونصف كوب من الحليب ونصف كوب من القهوة التركية.

عند وضع وعاء القهوة على قاعدة نقل الطاقة وتحويل المقبض الدوار إلى موضع الوضع المطلوب ، سيضيء ضوء الرمز للوضع المحدد باللون الأزرق وسيتم إطفاء أضواء الوضع الآخر. عندما تبدأ عملية التخمير ، سيقوم المحرك الموجود في وعاء القهوة بتقليب قهوتك تلقائيًا. بعد الانتهاء من عملية التخمير ، سيعطي جهازك تحذيرًا مسموعًا لمدة 5 ثوان وسيومض ضوء الوضع المحدد. لا تقم أبدا بإزالة وعاء القهوة أثناء التخمير. عند إزالة وعاء القهوة لأي سبب أثناء عملية التخمير ، سيعطي المنتج تحذيرًا مسموعًا وسيتم إيقاف تشغيل جميع رموز الوظائف الموجودة على اللوحة.

عند الانتهاء من عملية التخمير ، يمكنك تقديمها بسهولة عن طريق إزالة

الوعاء.
قم دائماً بتنظيف إناء الطهي بعد كل استخدام. لا تغسل السطح الخارجي لإناء الطهي تحت الحنفية، بل امسحه بقطعة قماش مبللة. لا تغسل إبريق القهوة في غسالة الأطباق أبداً.

إعداد كشف نقطة الإنتقاع (نظام كشف ارتفاع التحضير التلقائي)

يحتوي أرزوم أوكا ريتش سبين برو (Arzum OKKA Rich Spin Pro) على نظام ذكي "الكشف التلقائي عن ارتفاع التخمر" الذي يكتشف درجة حرارة التخمر المثالية في موقعه ويمكنك من صنع القهوة التركية بنفس النكهة في أي مكان في العالم.

تعتمد نقطة غليان الماء على الاختلاف في الارتفاع بالنسبة لمستوى سطح البحر. لذلك ، عندما يتغير الارتفاع الذي يتم فيه استخدام جهازك ، يمكنك ضبط نقطة تخمير جهازك يدوياً.

a. قم بتوصيل الجهاز بالمقبس.

b. اضغط على زر التشغيل / الإيقاف (المقبض الدوار) على اللوحة.

c. ستومض جميع مصابيح LED الموجودة على اللوحة وسيصدر صوت تنبيه مزدوج.

d. حدد وضع التخمر البطيء (☺) عن طريق تدوير المقبض الدوار. لا تضغط.

e. قم بإزالة وعاء القهوة واضغط على المقبض الدوار لفترة وجيزة.

f. بعد الصافرة ، سيبدأ مؤشر LED لوضع التخمر البطيء في الوميض ، ثم سيكون وضع المعايرة اليدوية نشطاً.

g. صب الماء في وعاء القهوة حتى مستوى MAX وأدخل وعاء القهوة في فتحته.

h. ز انتظر حتى يغلي الماء في وعاء القهوة.

i. عند الانتهاء من عملية المعايرة ، سيصدر جهازك صوتاً لمدة 5 ثوان وسيومض ضوء LED البطيء.

z. عند إزالة وعاء القهوة من فتحته ، سيصدر منتجك صوتاً مرة واحدة وسيتم إيقاف تشغيل جميع مصابيح LED.

إعداد درجة حرارة التخمر


يمكنك زيادة أو تقليل درجة حرارة تخمير القهوة كما يحلو لك ، وبذلك تصل إلى درجة الحرارة المطلوبة.

زيادة درجة الحرارة:

• قم بتوصيل المنتج بالمقبس.

• اضغط مع الاستمرار على زر التشغيل / الإيقاف (مقبض دوار).

• ستومض جميع مصابيح LED الموجودة على اللوحة مرة واحدة وسيصدر صوت تنبيه مزدوج.

• حدد وضع قهوة الحليب () عن طريق تدوير المقبض الدوار. لا تضغط. لا تضغط.

• أخرج وعاء القهوة من الفتحة.

• اضغط على المقبض الدوار 1 مرة.

• بعد الصافرة ، سيبدأ مؤشر LED الخاص بوضع القهوة التركبية مع الحليب في الوميض وسيكون وضع ضبط درجة حرارة التخمير اليدوي نشطا.

• يمكنك زيادة درجة الحرارة عن طريق تدوير المقبض الدوار في اتجاه عقارب الساعة. سيصدر صوت صفير في كل مرة يتم فيها تشغيل المقبض الدوار.


• ستزيد درجة الحرارة بمقدار 1 درجة مئوية لكل دورة. الزيادة المسموح بها في درجة الحرارة هي 1 درجة مئوية كحد أقصى.

• سيصدر صوت صفير مزدوج عند الوصول إلى الحد الأقصى. تخفيض درجة الحرارة:

• قم بتوصيل المنتج بالمقبس.

• اضغط مع الاستمرار على زر التشغيل / الإيقاف (مقبض دوار).

• ستومض جميع مصابيح LED الموجودة على اللوحة مرة واحدة وسيصدر صوت تنبيه مزدوج.

• حدد وضع قهوة الحليب () عن طريق تدوير المقبض الدوار. لا تضغط. لا تضغط.

• أخرج وعاء القهوة من الفتحة.

• اضغط على المقبض الدوار 1 مرة.

• بعد الصافرة ، سيبدأ مؤشر LED الخاص

بوضع قهوة الحليب في الوميض وسيكون وضع ضبط درجة حرارة التخمير اليدوي نشطا.

• يمكنك تقليل درجة الحرارة عن طريق تدوير المقبض الدوار عكس اتجاه عقارب الساعة.

سيصدر صوت صفير في كل مرة يتم فيها تشغيل المقبض الدوار.

• ستخفض درجة الحرارة بمقدار 1 درجة مئوية لكل دورة. الحد الأقصى المسموح به لانخفاض درجة الحرارة هو 3 درجات مئوية.

• سيصدر صوت صفير مزدوج عند الوصول إلى الحد الأقصى.

4. تخمير (لوضع القهوة التركبية الكلاسيكية)

1. قم بتوصيل القابس في المأخذ الكهربائي.

2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على



اللوحة

ملاحظة: انتبه إلى عدم تجاوز خليط الماء والقهوة والسكر أو الحليب إلى ما بعد خط مستوى MAX COFFEE في وعاء القهوة حيث قد يختلف حجم الأكواب التي تستخدمها.

3. لتحضير 1 فنجان من القهوة التركية؛ ضع 1 ملعقة قياس من أرزوم أوكا (Arzum OKKA) من القهوة التركية وفنجان ماء وأي كمية من السكر التي تريدها في إناء الطهي.

4. أدخل وعاء القهوة في الجهاز.

ملاحظة: ستبقى جميع المصابيح الموجودة على اللوحة مطفأة إذا لم يكن إناء الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير من عدم وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.

5. أدر المقبض الدوار لتحديد وضع القهوة التركية الكلاسيكية () واضغط عليه.

6. عند تحديد أي وضع تخمير، سيصدر صوت تنبيه وسيظل مؤشر LED الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.

7. سيصدر جهازك صوتاً تحذيرياً لمدة 5 ثوانٍ وسيومض ضوء الإضاءة المحيط وضوء وضع الطهي المختار عند اكتمال عملية الطهي.

8. قم بتقديم قهوتك في فنجان بعد انتهاء عملية الطهي.

9. إذا قمت بإزالة إناء الطهي قبل الانتهاء من عملية الطهي فإن مصباح التحذير باللون الأحمر الخاص بعدم وجود إناء طهي القهوة في مكانه وجميع مصابيح الوظائف سوف تقوم بالوميض وسوف ينهي جهازك عملية الطهي من خلال إصدار صوت تحذير.

لن تستمر عملية الطهي إذا تم إعادة إناء الطهي إلى مكانه بعد إزالته.

5. تخمير (وضع التخمير البطيء)

1. قم بتوصيل القابس في المأخذ الكهربائي.

2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على

اللوحة

ملاحظة: انتبه إلى عدم تجاوز خليط الماء والقهوة والسكر أو الحليب إلى ما بعد خط مستوى MAX COFFEE في وعاء القهوة حيث قد يختلف حجم الأكواب التي تستخدمها.



3. لتحضير 1 فنجان من القهوة التركية؛ ضع 1 ملعقة قياس من أرزوم أوكا (Arzum OKKA)

من القهوة التركية وفنجان ماء وأي كمية من السكر التي تريدها في إناء الطهي.

4. أدخل وعاء القهوة في الجهاز.

ملاحظة: ستبقى جميع المصابيح الموجودة على اللوحة مطفأة إذا لم يكن إناء الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير من عدم وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.

5. أدر المقبض الدوار لتحديد وضع التحضير البطيء (☺) واضغط على .

6. عند تحديد أي وضع تخمير ، سيصدر صوت تنبيه وسيظل مؤشر LED

الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.

7. سيصدر جهازك صوتاً تحذيرياً لمدة 5 ثوانٍ وسيومض ضوء الإضاءة المحيط وضوء وضع الطهي المختار عند اكتمال عملية الطهي.

8. قم بتقديم قهوتك في فنجان بعد انتهاء عملية الطهي.

9. إذا قمت بإزالة إناء الطهي قبل الانتهاء من عملية الطهي فإن مصباح

التحذير باللون الأحمر الخاص بعدم وجود إناء طهي القهوة في مكانه وجميع مصابيح الوظائف سوف تقوم بالوميض وسوف ينهي جهازك عملية الطهي من خلال إصدار صوت تحذير.

لن تستمر عملية الطهي إذا تم إعادة إناء الطهي الى مكانه بعد إزالته.

6. تخمير (للقهوة التركية مع وضع الحليب)

1. قم بتوصيل القابس في المأخذ الكهربائي.

2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على اللوحة

ملاحظة: في وضع القهوة التركية مع الحليب ، يمكن لجهازك تحضير القهوة لما يصل إلى 4 أشخاص في نفس الوقت. انتبه إلى عدم تجاوز خليط الماء والحليب والقهوة والسكر إلى ما بعد خط مستوى MAX MILK في وعاء القهوة حيث قد يختلف حجم الأكواب التي تستخدمها.

3. لإعداد 1 كوب من القهوة التركية مع الحليب. ضعي 1/2 ملعقة أرزوم أوكا

(Arzum OKKA) من القهوة التركية ونصف كوب ماء ونصف كوب حليب

والكمية المطلوبة من السكر في وعاء القهوة.

4. أدخل وعاء القهوة في الجهاز.

ملاحظة: ستبقى جميع المصابيح الموجودة على اللوحة مطفأة إذا لم يكن إناء

الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير من عدم

وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.

5. أدر المقبض الدوار لتحديد وضع القهوة التركية مع الحليب (☺) واضغط

على ذلك.

6. عند تحديد أي وضع تخمير ، سيصدر صوت تنبيه وسيظل مؤشر LED الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.
7. سيصدر جهازك صوتًا تحذيريًا لمدة 5 ثوانٍ وسيومض ضوء الإضاءة المحيط وضوء وضع الطهي المختار عند اكتمال عملية الطهي.
8. قم بتقديم قهوتك في فنجان بعد انتهاء عملية الطهي.
9. إذا قمت بإزالة إناء الطهي قبل الانتهاء من عملية الطهي فإن مصباح التحذير باللون الأحمر الخاص بعدم وجود إناء طهي القهوة في مكانه وجميع مصابيح الوظائف سوف تقوم بالوميض وسوف ينهي جهازك عملية الطهي من خلال إصدار صوت تحذير.

لن تستمر عملية الطهي إذا تم إعادة إناء الطهي الى مكانه بعد إزالته.

7. تخمير (لوضع الشوكولاته الساخنة)

في وضع الشوكولاتة الساخنة ، يوصى باستخدام 20 جم من الشوكولاتة الداكنة / الحليب و 200 مل من الحليب.

1. قم بتوصيل القابس في المأخذ الكهربائي.
2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على اللوحة



ملاحظة: انتبه إلى عدم تجاوز خليط الماء والحليب والسكر أو خليط الحليب بعد خط مستوى 200 مل في وعاء القهوة حيث قد يختلف حجم الأكواب التي تستخدمها.

3. أدخل وعاء القهوة في الجهاز.

ملاحظة: ستبقى جميع المصابيح الموجودة على اللوحة مطفأة إذا لم يكن إناء الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير

من عدم وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.

4. أدر المقبض الدوار لتحديد وضع الشوكولاتة الساخنة (☞) واضغط على.

6. عند تحديد أي وضع تخمير ، سيصدر صوت تنبيه وسيظل مؤشر LED

الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.

7. سيصدر جهازك صوتًا تحذيريًا لمدة 5 ثوانٍ وسيومض ضوء الإضاءة المحيط

وضوء وضع الطهي المختار عند اكتمال عملية الطهي.

8. بعد انتهاء عملية التخمير ، يمكنك تقديم مشروبك عن طريق سكب في

الكوب.

9. إذا قمت بإزالة إناء الطهي قبل الانتهاء من عملية الطهي فإن مصباح

التحذير باللون الأحمر الخاص بعدم وجود إناء طهي القهوة في مكانه وجميع

مصايح الوظائف سوف تقوم بالوميض وسوف ينهي جهازك عملية الطهي من خلال إصدار صوت تحذير.

لن تستمر عملية الطهي إذا تم إعادة إناء الطهي الى مكانه بعد إزالته.

8. تخمير (وضع مشروب الحليب)

يمكنك تحضير المشروبات التالية بجهازك في وضع المشروبات مع الحليب ؛

•قهوة الترتبتين (ميننجيتش)

•الحليب مع العسل

•سحلب

•ماتشا لاته

•وصفات أخرى يمكن تحضيرها بشراب القهوة

إعداد مشروب في وضع المشروبات مع الحليب ؛

1. قم بتوصيل القابس في المأخذ الكهربائي.

2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على

اللوحة

ملاحظة: انتبه إلى عدم تجاوز خليط الماء والحليب والقهوة والسكر أو خليط

الحليب بعد خط مستوى 200 مل في وعاء القهوة حيث قد يختلف حجم

الأكواب التي تستخدمها.

3. في وضع قهوة الحليب ، يمكن لجهازك تحضير ما يصل إلى 4 مشروبات في

المرة الواحدة.

4. أدخل وعاء القهوة في الجهاز.

ملاحظة: ستبقى جميع المصايح الموجودة على اللوحة مطفأة إذا لم يكن إناء

الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير من عدم

وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.

5. أدر المقبض الدوار لتحديد وضع المشروبات مع الحليب (☑️) واضغط

على ذلك.

6. عند تحديد أي وضع تخمير ، سيصدر صوت تنبيه وسيظل مؤشر LED

الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.

7. سيصدر جهازك صوتاً تحذيرياً لمدة 5 ثوان وسيومض ضوء الإضاءة المحيط

وضوء وضع الطهي المختار عند اكتمال عملية الطهي.

8. بعد انتهاء عملية التخمير ، يمكنك تقديم مشروبك عن طريق سكبته في

الكوب.

9. إذا قمت بإزالة إناء الطهي قبل الانتهاء من عملية الطهي فإن مصباح

التحذير باللون الأحمر الخاص بعدم وجود إناء طهي القهوة في مكانه وجميع

مصايح الوظائف سوف تقوم بالوميض وسوف ينهي جهازك عملية الطهي من

خلال إصدار صوت تحذير.

لن تستمر عملية الطهي إذا تم إعادة إناء الطهي الى مكانه بعد إزالته.
9. تسخين الحليب

لتسخين الحليب.

1. قم بتوصيل القابس في المأخذ الكهربائي.
2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على اللوحة
- ملاحظة: انتبه إلى عدم تجاوز كمية الحليب التي تتجاوز خط مستوى MILK في وعاء القهوة حيث قد يختلف حجم الأكواب التي تستخدمها.
3. أدخل وعاء القهوة في الجهاز.
- ملاحظة: ستبقى جميع المصابيح الموجودة على اللوحة مطفأة إذا لم يكن إناء الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير من عدم وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.
4. أدر المقبض الدوار لتحديد وضع تسخين الحليب (☺) واضغط على
5. عند تحديد أي وضع تخمير ، سيصدر صوت تنبيه وسيظل مؤشر LED الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.
6. بعد انتهاء عملية التسخين ، سيصدر جهازك صوتاً تحذيرياً لمدة 5 ثوانٍ وسيومض ضوء LED والإضاءة المحيطة لوضع التخمير المحدد.
7. بعد انتهاء عملية الاحترار ، صب الحليب في كوب وقدمه.
8. إذا قمت بإزاحة وعاء القهوة قبل انتهاء عملية التسخين ، فإن ضوء التحذير باللون الأحمر بأن وعاء القهوة ليس في مكانه وستومض جميع مصابيح الوظائف وسيصدر جهازك صوت تحذير وينتهي عملية التسخين.
- إذا تم إعادة وعاء القهوة بعد إزالته ، فلن تستمر عملية الاحترار.

10. رغوة الحليب (حار أو بارد)

1. قم بتوصيل القابس في المأخذ الكهربائي.
2. اضغط مع الاستمرار على زر التشغيل / الإيقاف (المقبض الدوار) على اللوحة

ملاحظة: انتبه إلى عدم تجاوز كمية الحليب التي تتجاوز خط مستوى 120 مل في وعاء القهوة لأن حجم الأكواب التي تستخدمها قد يختلف.

3. أدخل وعاء القهوة في الجهاز.

ملاحظة: ستبقى جميع المصابيح الموجودة على اللوحة مطفأة إذا لم يكن إناء الطهي في مكانه أو لم يتم تركيبه بشكل جيد، لكن ضوء التحذير من عدم وجود إناء القهوة وضوء الإضاءة المحيطة سيستمران في الإضاءة.



4. لرغوة الحليب البارد.
أدر المقبض الدوار لتحديد وضع رغوة الحليب البارد (☺) واضغط.
لرغوة الحليب الساخن.
أدر المقبض الدوار لتحديد وضع رغوة الحليب الساخن (☺) واضغط.
5. عند تحديد أي وضع تخمير ، سيصدر صوت تنبيه وسيظل مؤشر LED الأزرق فقط لوضع التخمير المحدد قيد التشغيل وستبدأ عملية التخمير.
6. بعد انتهاء عملية التسخين ، سيصدر جهازك صوتاً تحذيرياً لمدة 5 ثوانٍ وسيومض ضوء LED والإضاءة المحيطة لوضع التخمير المحدد.
7. بعد انتهاء عملية الرغوة ، صب الحليب في كوب وقدمه
8. إذا قمت بإزاحة وعاء القهوة قبل انتهاء عملية الرغوة ، فإن ضوء التحذير باللون الأحمر بأن وعاء القهوة ليس في مكانه وستومض جميع مصابيح الوظائف وسيصدر جهازك صوت تحذير وينتهي عملية التسخين.
إذا تم إعادة وعاء القهوة بعد إزالته ، فلن تستمر عملية الاحتراق.

الكمية	كلاسيكي	المشروب البطيء	قهوة الحليب
1 فنجان	0.5-1.5 دقيقة	2.5-3.5 دقيقة	1-2 دقيقة
2 فنجان	1-2 دقيقة	3-4 دقيقة	2-3 دقيقة
3 فنجان	2-3 دقيقة	3.5-4.5 دقيقة	3-4 دقيقة
4 فنجان	2.5-3.5 دقيقة	4-5 دقيقة	4-5 دقيقة
5 فنجان	3-4 دقيقة	5-6 دقيقة	

الكمية	المشروبات مع الحليب	الشوكولاته الساخنة	تسخين الحليب	رغوة الحليب الساخن والبارد
120 مل	2-4 دقيقة	3-4 دقيقة	1-2 دقيقة	1-2 دقيقة

11. التنظيف والصيانة

افصل قابس الجهاز من المأخذ الكهربائي قبل التنظيف. صب بعض الماء في إناء الطهي وقم بالخض لا تقم أبداً بتنظيف وعاء القهوة عن طريق غمره في الماء أو غسله في غسالة الصحون.

امسح الجسم الرئيسي لجهازك ، بما في ذلك قاعدة نقل الطاقة خارج وعاء القهوة ، فقط بقطعة قماش جافة أو مبللة ، ولا تقم أبداً بتنظيفه عن طريق غمره في الماء أو غسله في غسالة الصحون.



لا تقم بتنظيف أي ملحقات لجهازك باستخدام منظفات قاسية وكيميائية (مبيض ، ملح ، إلخ) بخلاف المنظفات المستخدمة لهذا النوع من المعدات. لا تستخدم المنظفات الكاشطة أو الأشياء المعدنية أو الإسفنج الصلب للخدش أو منظفات الأسلاك أو الفرش الصلبة لتنظيف الجهاز.

اقترح التنظيف بعد تحضير القهوة التركية بالحليب والمشروبات الحليبية

يمكنك أيضاً طهي المشروبات الحليبية مثل القهوة بالحليب والشوكولاتة الساخنة والسحلب باستخدام منتجنا. اشطف إناء الطهي بالماء بعد طهي هذا النوع من المشروبات. سوف يبرد إناء الطهي قليلاً بعد شطفه بالماء.

ثم قم بإزالة جهاز التقليل بالداخل وامسح الجزء الداخلي من إبريق القهوة بفرشاة التنظيف المرفقة مع جهازك أو بمادة ناعمة مثل إسفنجة غسل الأطباق أو قطعة قماش لتنظيف البقايا بسهولة * دون استخدام مواد كيميائية مثل المنظفات.

يمكنك غسل الخلاط الذي تم إزالته تحت الصنبور. يجعل المنتج جاهزاً للإستخدام عن طريق تركيب الخلاط الذي تم تنظيفه في مكانه مرة أخرى. تأكد من تركيب الخلاط في مكانه بشكل تام. الحالات التي لا يتم فيها تركيب الخلاط بمكانه بشكل تام قد تتسبب في تناثر السوائل. *يختلف تنظيف الترسبات/القشور المتراكمة اعتماداً على المواد المستخدمة وكمية المواد وفترة الانتظار بعد الطهي.

إزالة التكلس

قد يتراكم الجير داخل الماء المستخدم في الوقت المناسب داخل وعاء القهوة وبالتالي قد يقلل من أداء جهازك.

يمكنك تنظيف وعاء القهوة في جهازك باستخدام منتجات إزالة الكلس المصممة خصيصاً لأجهزة المطبخ الكهربائية أو تجربة حلول صديقة للبيئة

مثل الخل الأبيض.
لتنظيف وعاء القهوة من جهازك مع الخل الأبيض. أضف ما يكفي من الخل
الأبيض إلى الجهاز لتغطية قاع وعاء القهوة واتركه لمدة 1 ساعة ، ثم صفي
الخل واشطف وعاء القهوة 2-3 مرات بالماء النظيف.

12. الحمل والنقل

أثناء النقل، يجب الاحتفاظ بجهازك في علبته الأصلية لتجنب تلف مكوناته.
حافظ على المنتج في وضعه الطبيعي أثناء النقل.
لا تسقط جهازك أثناء النقل وقم بحمايته من الصدمات.
لا يغطي الضمان الأعطال والأضرار التي تحدث أثناء النقل بعد تسليم المنتج
إلى العميل.